



SUPERLIFT®

S U S P E N S I O N

Superlift Steering Arm or Steering Block INSTALLATION INSTRUCTIONS

INTRODUCTION

Installation requires a professional mechanic. Prior to beginning, inspect the vehicles steering, driveline, and brake systems, paying close attention to the suspension link arms and bushings, anti-sway bars and bushings, tie rod ends, pitman arm, ball joints and wheel bearings. Also check the steering sector-to-frame and all suspension-to-frame attaching points for stress cracks. The overall vehicle must be in excellent working condition; repair or replace all worn parts.

Read instructions several times before starting. Be sure you have all needed parts and know where they install. Read each step completely as you go.

NOTES:

- An arrow on diagrams indicates which direction is toward the front of the vehicle.
- A foot-pound torque reading is given in parenthesis () after each appropriate fastener.
- Do not fabricate any components to gain additional suspension height.
- Prior to attaching components, be sure all mating surfaces are free of grit, grease, undercoating, etc.
- A factory service manual should be on hand for reference.
- Use the check-off box "☐" found at each step to help you keep your place. Two "☐☐" denotes that one check-off box is for the driver side and one is for the passenger side. Unless otherwise noted, always start with the driver side.

INSTALLATION PROCEDURE

1) PREPARE VEHICLE...

- Put transmission in neutral. Position a floor jack under front axle and raise vehicle. Place jack stands under the frame rails, a few inches behind the front springs' rear shackles. Ease down the jack until frame is resting on stands. Keep a slight load on the jack. Put vehicle in gear or park, set emergency brake and chock rear wheels to prevent accidental of movement. Remove driver side tire.

2) DRAG LINK REMOVAL...

- Detach drag link from steering arm by using a tie-rod puller tool or "pickle fork". If neither tool is available, dislodge link by striking arm at the link-to-arm attaching point - do not strike the link end.
- Inspect the end's tapered stud. Replace end if any deformation / looseness is detected or if you can twist the stud in its socket with your fingers. If steering arm is being retained, inspect tapered hole for elongation and replace if necessary.

3) STEERING BLOCK / ARM INSTALLATION...

- Remove 3 nuts attaching steering arm-to-knuckle. The tapered split-locks are dislodged by striking the arm - do not strike studs. The stock mounting studs are replaced only when installing a steering block. Remove studs with a stud puller or use the jam nut method.
- Be sure all mating surfaces are free of nicks / burrs. For steering block installation, apply a liberal amount of the furnished thread locking compound to the stud-to-knuckle threads. Install and torque studs (110).
- Position Superlift steering block and / or arm and install split-locks. Apply thread locking compound to threads, install furnished 9/16" locking nuts, and torque(110).

4) DRAG LINK INSTALLATION...


- Attached draglink end to steering arm and tighten nut (85-110). If necessary, further tighten nut until castellation aligns with the cotter pinhole and install pin.

5) CENTERING THE STEERING WHEEL...

- Install the driver side tire using the torque values and procedure found in the factory service manual.

WARNING: Retighten lug nuts at 500 miles after any wheel change, or anytime the lug nuts are loosened. Failure to do so could cause wheels to come off while vehicle is in motion.

- The turning radius stop bolts are located on the front of the axle knuckles. Adjust both stop bolts all of the way in.
- Turn the steering wheel all the way to the right, then turn the wheel all the way to the left while counting the number of wheel revolutions. Now turn the wheel back to the right half the number of turns counted previously. This will put you within adjustment range of the correct setting. The steering wheel should now be "centered" with the wheel's crossbars positioned properly.
- Loosen the clamps on the drag link and adjust drag link length by rotating the adjustment / coupler sleeve so that the tires are pointing straight ahead. A "fine tuning" adjustment may be necessary after vehicle is driven.



- Tighten the drag link clamps to factory specifications.

6) TURNING RADIUS STOP ADJUSTMENT...

- With bolts adjusted all the way in, either the end of the sector's actual ability to turn or tire-to-leaf spring contact will limit turning. Adjust each stock bolt out until it limits turning at least 1/2" before tire contact or end of sector radius.

NOTE: The amount of adjustment may differ slightly. Longer Grade 8 bolts may be needed.

IMPORTANT: If a tire makes contact with a radius arm, tire damage may occur. This can also increase the possibility of vehicle rollover. If the steering sector is at full lock and receives a blow (rut, curve, etc.), steering linkage and / or steering sector main shaft failure may occur.

- Tighten the jamb nut on the turning radius stop bolts.

7) FINAL PROCEDURES...

- With the vehicle still on jack stands, and the suspension "hanging" at full extension travel, cycle steering lock-to-lock and check all components for proper operation and clearances. Pay special attention to the clearance between the tires / wheels and brake hoses, wiring, etc.
- Lower vehicle to the floor.
- With vehicle on floor, cycle steering lock-to-lock and inspect the tires / wheels, and the steering, suspension, and brake systems for proper operation, tightness, and adequate clearance.

Limited Lifetime Warranty / Warnings

Your Superlift® product is covered by the Limited Warranty explained below that gives you specific legal rights. This limited warranty is the only warranty Superlift® makes in connection with your product purchase. Superlift® neither assumes nor authorizes any retailer or other person or entity to assume for it any other obligation or liability in connection with this product or limited warranty.

What is covered? Subject to the terms below, Superlift® will repair or replace its products found defective in materials or workmanship for so long as the original purchaser owns the vehicle on which the product was originally installed. Your warrantor is LKI Enterprises, Inc. d/b/a Superlift® Suspension Systems ("Superlift®").

What is not covered? Your Superlift® Limited Warranty does not cover products, parts or vehicles Superlift® determines to have been damaged by or subjected to:

- Alteration, modification or failure to maintain.
- Normal wear and tear (bushings, tie-rod ends, etc.). Scratches or defects in product finishes (powdercoating, plating, etc.),
- Damage to or resulting from vehicle's electronic stability system, related components or other vehicle systems.
- Racing or other vehicle competitions or contests. Accidents, impact by rocks, trees, obstacles or other aspects of the environment.
- Theft, vandalism or other intentional damage.

Remedy Limited to Repair / Replacement. The exclusive remedy provided hereunder shall, upon Superlift's inspection and at Superlift's option, be either repair or replacement of product or parts covered under this Limited Warranty. Customers requesting warranty consideration should contact Superlift® by phone (1-800-551-4955) to obtain a Returned Goods Authorization number. All removal, shipping and installation costs are customer's responsibility.

If a replacement part is needed before the Superlift® part in question can be returned, you must first purchase the replacement part. Then, if the part in question is deemed warrantable, you will be credited / refunded.

Other Limitations - Exclusion of Damages - Your Rights Under State Law

- Neither Superlift® nor your independent Superlift® dealer are responsible for any time loss, rental costs, or for any incidental, consequential or other damages you may have.
- This Limited Warranty gives you specific rights. You may also have other rights that vary from state to state. For example, while all implied warranties are disclaimed herein, any implied warranty required by law is limited to the terms of our Limited Lifetime Warranty as described above. Some states do not allow limitations of how long an implied warranty lasts and / or do not allow the exclusion or limitation of incidental or consequential damages, so the limitations and exclusions herein may not apply to you.

Important Product Use and Safety Information / Warnings

As a general rule, the taller a vehicle is, the easier it will roll over. Offset, as much as possible, what is lost in rollover resistance by increasing tire track width. In other words, go "wide" as you go "tall". Many sportsmen remove their mud tires after hunting season and install ones more appropriate for street driving; always use as wide a tire and wheel combination as feasible to enhance vehicle stability. We strongly recommend, because of rollover possibility, that the vehicle be equipped with a functional roll bar and cage system. Seat belts and shoulder harnesses should be worn at all times. Avoid situations where a side rollover may occur.

Generally, braking performance and capabilities are decreased when significantly larger / heavier tires and wheels are used. Take this into consideration while driving. Also, changing axle gear ratios or using tires that are taller or shorter than factory height will cause an erroneous speedometer reading. On vehicles equipped with an electronic speedometer, the speed signal impacts other important functions as well. Speedometer recalibration for both mechanical and electronic types is highly recommended.

Do not add, alter, or fabricate any factory or aftermarket parts to increase vehicle height over the intended height of the Superlift product purchased. Mixing component brands is not recommended.

SUPERLIFT SUSPENSION SYSTEMS

300 Huey Lenard Loop Rd.
West Monroe, Louisiana 71292
Phone: (318) 397-3000
Sales / Tech: 1-800-551-4955
FAX: (318) 397-3040
www.superlift.com