



INSTRUCTIONS

1. Separate the slide members per the drawer slide mounting instructions and slide appropriate rear mounting bracket on the back of the drawer slide.
2. Attach the front of the slide to the face frame and extend the slide to the rear mounting surface making sure that the slide is level and perpendicular to the front. If necessary, add a strip to the back of the cabinet to provide a solid mounting surface for the rear bracket. Mark the rear mounting holes with a pencil.
3. Secure the rear mounting bracket with 3 #6 x ½" Truss Head wood screws.
4. Repeat for the other side of the drawer and complete the drawer mounting process per the drawer slide mounting instructions.