

INSTALLATION STEPS

1. Remove tow hooks if present.

2. Maneuver passenger side plate over the exhaust and hold hitch up against frame.

3. Line up holes in the hitch side plates to existing weldnuts in frame. Install M12 and M8 bolts as shown.

4. Torque all M12 fasteners to 86 ft.-lbs. Torque all M8 fasteners to 23 ft.-lbs.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.

Keystone Automotive Operations Inc., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, Keystone Automotive Operations Inc., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. Keystone Automotive Operations Inc.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage. This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York, V.E.S.C. Regulation V-5 and SAE J684. For Technical & Warranty Support: 1-877-544-4449 Fax-1-855-242-8922 www.huskytow.com