

SHOWER CURTAIN ROD

INSTALLATION INSTRUCTIONS

1. Trace screw hole positions for mounting bracket onto wall at desired mounting location.
2. Drill 3/16" (5mm) holes in drywall, 1/4" (6mm) in tile at screw hole marks. Insert anchors and tap flush with wall.
3. Position mounting bracket over anchors and install screws.
4. Slide rosette and adapter over each mounting bracket and tighten set screw with hex key.
5. Cut tube length to 1/16" less than the distance between the adapters. Remove burrs from tube end.
6. Slide o-ring end of sleeves over tube until tube protrudes slightly from other end of sleeves. Moistening the black rubber o-ring will allow the sleeves to slide more easily.
7. Position the tube and sleeves between the adapters and slide the sleeves over adapters.
8. Rotate the sleeves in a clockwise direction until the sleeves contact the rosettes.

APPLICATIONS:

Canterbury	Cassandra	Chelsea	Empire	Metro	Synchro
1539	1439	1139	639	0839	1939

CARE OF FINE BRASS

The finish is protected with a clear, durable, baked-on enamel. To clean, use warm soapy water, and dry with a soft cloth. Occasional paste waxing is also recommended. NEVER use brass polish, abrasives or abrasive wax.

