

# INSTALLATION INSTRUCTIONS

## BODY SPRAY ASSEMBLY

MODEL NO. 217, 2170, 2171, 2173, 2174, 2178

NEWPORT BRASS®

Flawless Beauty. From Faucet to Finish.™

**We recommend Installation of this product by a Professional Plumbing Contractor**

**Note:** The use of petroleum based plumber's putty on our products will nullify the warranty.

We recommend the use of clear silicone sealing materials.

**All trim must be installed on finished wall surface.**

**Important:** It is recommended that a 1/2"-pressure balance loop be plumbed for 2 or more body sprays. This technique will allow equal flow and temperature to each body spray.

### **Body Spray Installation:**

Based on finished wall thickness, installer must use an appropriate length 1/2" NPT NIPPLE (1), not included, for each Body Spray installation.

Apply thread sealant to both ends of the NIPPLE (1) and thread into FITTING (2) behind finished wall.

Attach body SPRAY (3) onto other end of NIPPLE (1).

Turn on water supply, check for leaks and make any final adjustments required.

