

WET-SET (NEW CONCRETE) INSTALLATION TUTORIAL

Read and follow the complete instructions affixed to each TufTile before you begin. Do not remove the protective film until the tile is installed and the concrete has cured overnight.



#1

#1 On the poured and leveled concrete, position the TufTile on its edge in the area where the tile is to be installed.

#2 Lay the TufTile, anchors facing down and make final position adjustments.

#3 Firmly press the TufTile into the wet concrete until the surface of the tile is even with the adjacent concrete. The domes should project above the adjacent concrete.



#2



#3



#4

#4 Tap the entire surface of the tile with a rubber mallet to ensure the concrete integrates with the anchors below the tile.



#5

#5

IMPORTANT: #5
Apply a troweled edge to the entire perimeter of the tile



#7

#6 Apply the final finish to the surrounding concrete. Allow the concrete to cure overnight before removing the protective film.

#7 Your installation is complete



#6



**CORRECT
TROWELED EDGE**

**MANDATORY
INSTALLATION
STEP:**

**A TROWELED
EDGE MUST BE
ADDED TO THE
ENTIRE
PERIMETER OF A
TUFTILE
DETECTABLE
WARNING TILE**



**INCORRECT
MISSING TROWELED**



**CORRECT
ANCHORS ADDED**

**MANDATORY
INSTALLATION
STEP:**

**ANCHORS MUST
BE ADDED BACK
TO ANY MODIFIED
EDGE OF A
TUFTILE
DETECTABLE
WARNING TILE**



**INCORRECT
MISSING EDGE ANCHORS**