How to properly install Protect-A-Bed® Bed Bug Encasements



Lift mattress up against the wall.



Align the corners of the cover with the corners of the mattress and pull down encasement.



Make sure that the top corners are properly aligned before closing the zipper.



Place the mattress back onto the box-spring.



Zip up the cover all around the mattress.



Close the zipper completely and attach the Secure Seal* zip tie to ensure complete bed bug protection.

Before Installing Box Spring Encasement

- Always install products with two (2) or more people.
- Always install felt strips and/or commercial grade duct tape to contact points with bed frame.
- Do NOT drag installed encasements onto bed frame or along the floor.
- BEWARE of sharp corners or points; these WILL puncture the encasement.
- Box spring corner guards may need to be taped to prevent ripping of the encasement.