


Cambridge

designer planter




* The plastic plug is placed in the bottom of the planter to seal a vent hole from the manufacturing process. There is no need to remove this plug.

GENERAL INFORMATION:

- Avoid using garden soil or topsoil for container planting, it's often too dense and restricts air circulation. A potting mix is strongly recommended and will ensure better plant growth.
- Rinse clean with a garden hose; for a deeper clean, use a power washer.
- The polyethylene construction is designed to withstand cold temperatures, but winter storage is recommended in extremely cold conditions.
- **15-year** warranty residential use, **5-year** warranty commercial use.

Polyresin Planter
Indoor/Outdoor Use
UV Protected
Shock Resistant
All-Weather Material



Remove fill port plug for direct access to the water reservoir.

WARNING

Children can fall into planter and drown.
Keep children away from planter with even a small amount of liquid.