

Stand Up Bookcase LBC4123 • INSTRUCTIONS You will need 2 person(s) for this assembly. You will need a Phillips head screw driver.


Hardware: A: Cam Pins(13) • B: 12 Cam Caps(12) • C: Wood Screws(4) • D: Shelf Pins(8)



Figure 1: To open Cam, point arrow toward Cam Pin hole. To lock Cam, turn clockwise.



Parts: E: Top Support(2) • F: Bottom Stringer(1) • G: Bottom(1) • H: Back(1) • I: Side(2) J: Shelves(2)




IMPORTANT NOTICE:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Do not tighten all screws/bolts until completely assembled.
- Keep all hardware parts out of reach of children.



You will need 2 person(s) for this assembly. You will need a Phillips head screw driver.



IMPORTANT NOTICE:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Do not tighten all screws/bolts until completely assembled.
- Keep all hardware parts out of reach of children.