

# REGENCY





## Legacy Return Shell • LRT3024 • LRT3524 • LRT4724 • INSTRUCTIONS

Organize your parts and hardware | You will need a Phillips head Screwdriver

### Parts:



### Hardware:



**IMPORTANT: Decide Return orientation before assembly**


### Left Return



### Right Return



**STEP 1 :** Insert 3 Cam Pins (D) and 2 Dowel Rods (E) into Leg (C). **IMPORTANT:** Note placement of hardware for Left and Right Return orientations.



### IMPORTANT NOTICE:


- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Keep all hardware parts and packaging out of reach of children.

# REGENCY


Legacy Return Shell • LRT3024 • LRT3524 • LRT4724 • INSTRUCTIONS

**STEP 2 :** Insert 5 Cam Pins (D) into Top (A). *IMPORTANT: Note placement of hardware for Left and Right Return orientations.*


Left Return



Right Return




**STEP 3 :** Attach Leg (C) to Modesty Panel (B) by lining up Cam Pins (D) and Dowel Rods (E) with their respective holes. Lock Cams (see Figure 1).




**Figure 1:** To open Cam, point arrow to Cam Pin Hole. To close and lock Cam, turn clockwise

**STEP 4 :** Attach Top (A) to assembled portion in a similar manner. Ensure all Cams are locked before proceeding.



**STEP 3a :** Attach Corner Brackets (H) to assembled Return  
**STEP 3b :** Install Caps & Covers (J, K, L) on Cams and unused pre-drilled holes



**STEP 4 :** Use Large Corner Bracket (F) and Flat Brackets (G) to attach Return to Desk

