

MTS46 & MTS60 • Table Stiffener INSTRUCTIONS You will need a Phillips Head Screw Driver or Drill and a Tape Measure to Assemble.


Hardware:

A: Self Tapping Screws (Quantity varies according to Stiffener size)


A TIME


Parts:

B: Table Stiffeners (2) • **C**: Table Top (may vary) • **D**: End Caps (4)



STEP 1A: Slide End Caps(D) onto the ends of both Table Stiffeners(B) apply pressure until the holes align. (see figure 1)





STEP 1B: Place Table Top(C) on a clean flat surface with desired table finish face down. Position Table Stiffeners(B) and applied End Caps(D) in the center of the Table Top lengthwise, leaving equal space on each side.

Next position Table Stiffeners(B) and applied End Caps(D) spaced evenly across the width.

Note: May be adjusted to accommodate power blocks or other under-the-table accessories as needed.



STEP 2: Attach Table Stiffeners(B) and applied End Caps(D) to Table Top(C) by using all of the included Screws(A).

IMPORTANT NOTICE:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Do not tighten all screws/bolts until completely assembled.
- Keep all hardware parts out of reach of children.