

# UNIVERSAL THREAD REPAIR



## EXTERNAL THREAD REPAIR



NES06040



NES1A



NES2



NES3

- External tools restore inch or metric, right hand or left hand fastener threads
- Floating cutters are self-adjusting to any pitch and size within range
- No need for calibration or identifying thread type
- Automatically chases good thread sections to repair the damaged parts

WATCH VIDEO



ITEM #	OUTER DIAMETER	PIPE DIAMETER	LBS.
NES1A	5/32" - 11/16"	up to 7/16"	.50
NES2	11/16" - 1.1/2"	3/8" - 1.1/8"	1.21
NES3	1.3/8" - 6"	1" - 5.1/2"	4.29
NES06040	5/32" - 1/2"	up to 1/4"	.38

## INTERNAL THREAD REPAIR



NES21



NES23



NES25



NES27

- One hand tool restores inch or metric, right hand or left hand fastener threads
- Floating cutters are self-adjusting to any pitch and size within range
- No need for calibration or identifying thread type
- Nylon pads available to avoid marring softer metals

WATCH VIDEO



ITEM #	OUTER DIAMETER	PIPE DIAMETER	LBS.
NES21	5/16" - 7/16"	1/16" - 3/16"	.35
NES22	1/2" - 5/8"	1/4" - 3/8"	.37
NES23	11/16" - 13/16"	3/8" - 1/2"	.55
NES24	7/8" - 1.1/4"	1/2" - 7/8"	1.00
NES25	1.1/4" - 2.1/8"	7/8" - 1.3/4"	2.10
NES26	1.1/4" - 2.5/8"	7/8" - 2.1/4"	2.40
NES27	2.3/4" - 3.3/16"	2.3/8" - 2.3/4"	3.10
NES28	3.1/4" - 3.3/4"	2.3/4" - 3.1/4"	3.20
NES29	3.3/4" - 4.1/4"	3.1/2" - 3.3/4"	3.30
NESTM20	#12 - 5/16"		.30
NESTM21	5/16" - 7/16"		.30