

EasyWipe

Disposable Wiping System



The EasyWipe Disposable Wiping System provides the flexibility and ease to create customized cleaning wipes by simply adding the cleaner, disinfectant or sanitizer of your choice.

Versatile

- ▶ Can be used with a variety of Diversey cleaners, disinfectants and sanitizers
- ▶ Use on all hard, nonporous surfaces that are outlined on the chemical label
- ▶ Bucket can be re-used with an EasyWipe refill

Effective

- ▶ Specially-treated wipers do not bind with cleaning chemicals or disinfectant actives
- ▶ High quality fibers allow for easy pick-up and removal of dirt, dust and other soils
- ▶ Individual wipers in an enclosed system reduce the risk of surface cross-contamination, chemical splashes and spills

Efficient

- ▶ Allows for dispensing of individual cleaning wipes, no wringing required
- ▶ Bucket closure system allows the wipes to be used across shifts, saving time and money
- ▶ Helps reduce chemical waste providing an accurate chemical load on each wipe
- ▶ Ideal for facilities with no laundering capability

Designed For

- ▶ Healthcare
 - ▶ Education
 - ▶ Retail
 - ▶ BSC
 - ▶ Government
 - ▶ Lodging
-



Specifications

The **EasyWipe Disposable Wiping System** is the perfect choice for dust and dirt removal in facilities with no laundering capabilities. Pre-wetted disposable wipes can replace traditional spray-and-wipe cleaning.

Use Instructions:

- ▶ Ensure the EasyWipe Disposable Wiping System is compatible with the desired type of chemical solution. Read Material Safety Data Sheet (MSDS) and test the chemical solution with the wipes to determine compatibility.
- ▶ Understand any hazards related to the chemical solution and its use by consulting its MSDS. Follow all applicable safety advice and use appropriate protective equipment. For questions about safe chemical solution use, contact your supervisor or site occupational safety professional.
- ▶ Fill out the label with all information about the added chemical solution or apply the appropriate aftermarket label to the bucket.

Note: This label does not replace the manufacturer or supplier's MSDS.

- ▶ Slowly pour chemical solution over the top of the roll. Use approximately one half gallon (74 oz/1.9 L) of chemical solution in the 1 gallon (3.78 L) bucket. More or less liquid may be required to obtain the desired saturation level.
- ▶ Thread the end of the wiper from the CENTER of the roll through the lid opening. Snap the lid on.



Technical Data

Description	
Color	White
Material	Meltblown Polypropylene
Size	12.5 x 10.6 in (31.8 x 26.9 cm)

Ordering Information

Model	Quantity	SKU Number
EasyWipe Disposable Wiping System	6 x 120 wipes	5768748
EasyWipe Disposable Wiping System Refill	6 x 120 wipes	5831874
Disposable Mop - 60 cm	250 ct.	3345274
Disposable Mop - 40 cm	250 ct.	3345266