

CREST**CLEANGRIP™**

Plastic Anti-Ligature Tethers

Designed with patient well-being & safety in mind



CleanGrip Plastic Anti-Ligature Tethers

Safe and easy to grab, the Crest CleanGrip is a highly visible and cleanable alternative to nylon station pullcords. The CleanGrip tether is constructed of 12 mm wide PVC that is 1.8 mm thick. It is easily disinfected by germicidal detergent, disposable wipes or disinfectant cleaner. The anti-ligature safety feature is created with strategic placement of "breaks" every 4" along the length of the cord when 22 lbs of force is exerted. CleanGrip is available in non-preassembled configurations and in bulk rolls.

- Bulk tether can be cut to any desired length
- Available in red or blue to provide contrast for high visibility
- Adapter connects to CleanCord™ Pullcords, as well as functioning as a pendant & bead chain adapter
- Compare with Sanipull® for a better value

Part No. Description

- [116601](#) CleanGrip Anti-Ligature Tether, blue, 6', 1 pack (5/pk)
- [116602](#) CleanGrip Anti-Ligature Tether, red, 6', 1 pack (5/pk)
- [116158](#) CleanGrip Anti-Ligature Tether with two Adapters, blue, 6'
- [116387](#) CleanGrip Anti-Ligature Tether with two Adapters, red, 6'
- [116606](#) CleanGrip Anti-Ligature Tether with Security Clip and Adapter, blue, 6'
- [116607](#) CleanGrip Anti-Ligature Tether with two Security Clips, blue, 6'
- [116608](#) CleanGrip Anti-Ligature Tether with Security Clip and Adapter, red, 6'
- [116609](#) CleanGrip Anti-Ligature Tether with two Security Clips, red, 6'
- [115840](#) CleanGrip Anti-Ligature Tether with two Adapters, #6 Bead Chain and Coupling, blue, 6'
- [116157](#) CleanGrip Bulk Anti-Ligature Tether, blue, 500'
- [116375](#) CleanGrip Bulk Anti-Ligature Tether, red, 500'
- [115842](#) CleanGrip Adapter, attaches to cords or bead chains, red, 1pk (10/pk)
- [116613](#) CleanGrip Replacement Clip Kit, 1 pack (10/pk)



116387



115840

LATEX-FREE

1
YEAR
WARRANTY

Installation Instructions

#6 Bead Chain

Insert #6 Bead Chain into adapter through small hole on top then attach coupling unit to bead chain. Rest coupling unit within adapter. Fold CleanGrip tether twice. Insert into adapter next to coupling. Snap adapter closed.

Screw & Nut

Trim the CleanGrip tether, if needed, in a straight line. Using a 3/32" drill bit, drill a hole centered 1/4" from the end of the CleanGrip tether. Insert provided screw through the security clip and CleanGrip hole. With black sleeve facing downward, secure nut to the screw.

Plastic & Nylon Pullcords

Insert thin nylon cord into adapter through small hole on top. Tie knot and rest cord within adapter to prevent pull through. Fold CleanGrip tether twice. Insert into adapter next to nylon cord. Snap adapter closed.

Tether

Fold CleanGrip tether twice. Insert into adapter and make sure it is snug. Snap adapter closed.

Video Available on YouTube

CREST
HEALTHCARE®

800.328.8908

800.369.9207

CrestHealthcare.com

©2022 Crest Healthcare. All listed prices and products are subject to change without notice. Crest is not responsible for photographic or typographical errors.